

MASONRY OR BRICK

- ✔ A drywall is recommended when affixing GearWall[®] panels to any brick or masonry surface for a more level surface and ease of application. (Refer to installing on Timber or Timber Studs hints).
- ✔ Measure and cut GearTrack[®] and or GearWall[®] Panels.
- ✔ Pre drill your masonry wall and insert 6mm (green) star plugs before locating your gear track using a hammer drill and a masonry drill bit.
- ✔ Pre drill GT & GW separately as masonry bit will be too big for screws.
- ✔ When drilling in the screws, start at the centre of the GearTrack[®] or Gear Wall[®]. The next two points are located half the distance from the centre to the end (each side of centre) Finally 10-20mm in from both ends, this will give you a total of ten location points (Five top and five below).
- ✔ Ensure your Gladiator[®] wall system is level before affixing your second screw and periodically check that your GearTrack[®] and or GearWall[®] Panels are level. When installing GearWall[®] Panels start from the bottom and work up. Check to see that all screws are in every slot location evenly top and bottom of the panels on the structural studs.
- ✔ **Tools Required**
 - Marking pencil
 - Measuring tape
 - Level
 - Cordless drill with a Phillips Head or a Phillips Head screw driver
 - Hammer drill
 - Masonry drill and 5-5.5mm masonry drill bit
 - 6mm star plugs
 - Hand saw or circular saw

